



S1 LANTERN



Recommended Care for your TITAN S1 Pitched Lantern

We recommend the following steps of glass cleaning process:

Firstly, carefully rinse the lantern thoroughly with clean water to remove as much dust, stones, sand and any kind of dirt as possible - all of them may scratch the surface of the frame and glass.

Remove remaining dirt from the lantern gently using a large amount of clean water and a hand window cleaner with soft material cover (or soft cloth). Please remember to rinse the soft material cover or cloth with water to remove dirt as frequently as possible.

Check there are no stones, dust, sand or any dirt left on the lantern that could scratch its surface. If the glass surface is clean dry with a soft, clean cloth.



TITAN
ALUMINIUM

NB: Do not use pressure washers on your lantern.